




ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 44 NEW




ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 44 NEW

1	Housing	120223	
2	Panel	110516	
3	Right Cover	110513	
4	Left Cover	110514	
5	Door Frame	120218	
6	Chamber-Complete	120220	
7	Door-Complete	120214	
8	Flue	120144	
9	Top Electrical Sheet	110505	
10	Bottom Electrical Sheet	110506	
11	Thermostat Button	220024	
12	Light On-Off switch	220025	
13	Thermostat	220026	
14	Green Indicator light	220023	
15	Thermometer	220029	
16	Stone	230019	
17	Power Terminal Holder	110339	
18	Housing Leg	110495	
19	Pako switch	220030	
20	Heating Element 1150	230016	
21	Heating Element 1350	230017	
22	Rear Insulation	110518	
23	Right Insulation	110517	
24	Horizontal Insulation	110508	
25	Left Insulation	110518	
26	Flue Insulation	110337	
27	Thermocouple Holder	110026	
28	Upper Heating Element Holder	110507	
29	Chamber Light	220031	

ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 44 OLD



ПЕЧЬ ДЛЯ ПИЦЦЫ TATRA TPO 44 OLD

1	Housing	E072203	
2	Side Panel	E072209	
3	Left Cover	E072204	
4	Door Frame	E070008	
8	Door complete	E070001	
9	Panel	E072206	
10	Base	E070013	
21	Bracket for Thermostat	E050121	
23	Bracket for Thermostat	E050123	
25	Fixing for Heating Element	E050126	
30	Heating Element (Upper and Lower front ones) 1150 W	CP700-1150WHE	
30.A	Heating Element (Upper and Lower front ones) 1350 W	CP700-1350WHE	
31	Knob, black-chromed for thermostat	EOANOT235	
32	Green indicator Light,complete	043828	
33	Thermostat 455°C	OT45SEGO	
34	Refracter Stone(Italian)	CP700-700.355	
35	Handle with connect part, big	EOBK600N	
37	Connector, 2-poles, ceramic for lamp	CRMO057KLMS	
39	Lamp On/Off Switch	A040588	
40	Control Panel Sticker	EOQ15ETKT	
41	Door glass	E049371	
47	Thermometer	E000521506	
48	Bracket for hesting element	E070099	
49	Halogen Lamp w.cover glass, square	EO15ELCSQ	
	Halogen Bulb G9	06061056	
51	Therminal box	T00133BX	
52	Connector with 2 poles	E073071	
53	Connector with 3 poles	E0730733	
54	Strain Relief PG21	010578030	