



IX- SPARE PART LIST





NO	SPARE PART CODE	NAME
1	M008579	Skewer Profile Top
2	M009219	Motor Group
3	M010578	Keeper Part
4	M011487	Motor Profile
5	M011488	Bottom Skewer Part
6 (For 3 burner)	M011618	Skewer
6 (For 4 burner)	M011632	Skewer
6 (For 5 burner)	M011633	Skewer
7	M011667	Skewer Lock Mechanism
8	M012439	Tray's inside part
9	P011783	Mirror
10	P013223	Tray
11	P013257	Tap
12	P018430	Mirror
13	P950508	M5x08 S.B. SS SCREW
14	P004671	Rekor
15	P011766	1/0/2 Button
16	P015344	Crouzet Motor
17	P019074	Skewer Lock Mechanism Part
18	P019075	Skewer Part / Pipe
19	P019076	ø3x16 SS Part
20	P019112	Part
21	P020036	Cable
22	P020038	Feeding Cable
23	P131004	M4 SS PART
24	P810410	M4x10 SS SCREW
25	P810425	M4x25 SS SCREW
26	P000177	Plastic Cable PG16
27 (For 3 burner)	P004209	Glass
27 (For 4 burner)	P002691	Glass
27 (For 5 burner)	P004210	Glass
28	P006575	Paco Switch
29	P006630	Plug
30	P007156	Resistance Stone
31	P007514	Button
32	P021122	Feeding Cable
33	P025452	Under Stone Insulation
34	P025478	Resistance
35	P006659	MVK 2,5 conductor connection apparatus - grey
36	P006666	MVK 2,5 conductor connection apparatus - blue
37	P006667	MVK 2,5 conductor connection apparatus – green / yellow
38	P006679	Conductor connection apparatus part -5 / grey
39	P027803	Conductor connection apparatus tap, MVK, 2.5-4 Grey
40 (For 3 burner)	M012992	Left Wing
40 (For 4 burner)	M012995	Left Wing
40 (For 5 burner)	M012998	Left Wing
41 (For 3 burner)	M012991	Right Wing
41 (For 4 burner)	M012994	Right Wing
41 (For 5 burner)	M012997	Right Wing
42	P036533	Wing Part